



Perches Manuelles		
N°	Hr. MINI	Hr. MAXI
M1	0	8.68
M2	0	8.68
M4	0	8.68
M6	0	8.68
M7	0	8.68

Perches Electriques		
N°	Hr. MINI	Hr. MAXI
A	0	8.68
1	1.48	7.93
2	1.46	8.01
3	1.46	7.98
4	1.50	7.99
5	0	8.68
6	1.44	7.95
7	1.50	8.02
8	1.51	8.01
9	1.48	8.06
10	1.58	7.86
11	1.47	8.01
12	1.49	8.05
E	0	6.60
Fosse d'Orchestre		
F	0.95	8.28

